

PHOENIX 200

HIGH CAPACITY DEHUMIDIFIER

Therma-Stor Products

A Division of DEC International
Box 8050 Madison, WI 53708

Toll Free 1-800-533-7533

Local 1-608-222-5301



PHOENIX 200 Operation & Service Instructions

Table of Contents

- 1. Specifications 1
- 2. Operation 1
 - 2.1 Transporting the Phoenix 200 1
 - 2.2 Location 1
 - 2.3 Electrical Requirements 2
 - 2.4 Condensate Removal 2
 - 2.5 Ducting 2
 - 2.6 Power Switch 2
 - 2.7 Pump Purge Switch 2
 - 2.8 Hour Meter 2
 - 2.9 Defrost Control Adjustment 2
 - 2.10 Low Pressure Control 3
- 3. Maintenance 3
 - 3.1 Air Filter 3
 - 3.2 Blower Oiling 3
 - 3.3 Storage 3
- 4. Service 4
 - 4.1 Warranty 4
 - 4.2 Technical description 4
 - 4.3 Troubleshooting 4
 - 4.4 Refrigerant Charging 5
 - 4.5 Blower Replacement 5
 - 4.6 Compressor/Capacitor Replacement 5
 - 4.6A Checking Compressor Motor Circuits 5
 - 4.6B Replacing a Burned Out Compressor 6
 - 4.6C Replacing a Compressor- Non-Burn Out... 7
 - 4.7 Defrost Thermostat & Timer 7
 - 4.8 Condensate Pump 7
 - 4.9 Gravity Drain Option 7
 - 4.10 Relay 7
- 5. Wiring Diagram 8
- 6. Service Parts List 9

Read the operation and maintenance instructions carefully **before** using this unit. Proper adherence to these instructions is essential to obtain maximum benefit from your Phoenix 200 dehumidifier.

1 Specifications

Model: PHOENIX 200 Dehumidifier
 Electrical: 110-120 Vac, 7.2 Amps, grounded
 Capacity: 121 pints/day @ 80°F, 60% RH
 Operating Temp. Range: 33°F min., 105°F max.
 Air Flow: 255 CFM without external ducting
 170 CFM @ .15 IWG external static
 Refrigerant Charge: 1 lbs., 14 oz. R-22
 Optional Duct connection: 8" round outlet
 Size (w/o duct collar): 41" high x 24" wide x 20" deep
 Weight: 132 lbs.

2 Operation

2.1 Transporting the Phoenix

The Phoenix 200 must always be upright when transported by vehicle. It may be tipped on to its handle and back for loading and moving by hand.

2.2 Location

Note the following precautions when locating the Phoenix 200:

It is designed to be used **INDOORS ONLY**.
 If used in a wet area, plug it into a **GROUND FAULT INTERRUPTER**.

DO NOT use the Phoenix 200 as a bench or table. It must always be used in the upright position. The air inlet on top & the side outlet must be at least 1 foot from walls and other obstructions to air flow. If the humid area is very large, dehumidification can be improved by adding an outlet duct to circulate air to stagnant areas (see Sec. 2.5).

Serial No. _____

Purchase Date _____

Dealer's Name _____

2.3 Electrical Requirements

The Phoenix 200 plugs into a common grounded outlet on a 15 Amp circuit. It draws 7.2 Amps at 80F, 60%RH. Amp draw increases with increasing temperature and/or humidity; e.g. 10.2 amps at 90F, 85%RH. If used in a wet area, a ground fault interrupter (GFI) is required. Detachable GFI plugs that can be connected to the end of the Phoenix 200 cord are available from Therma-Stor.

If an extension cord is required, it must have a minimum of 14 gauge conductors if 25 feet long or less and 12 gauge conductors if greater than 25 feet long.

2.4 Condensate Removal

The Phoenix 200 is equipped with an internal condensate pump to remove the water that is condensed during dehumidification. This allows the condensate to be pumped 30' with the attached hose. If the condensate must be pumped more than 20 feet above the unit, a second pump must be added to relay the condensate. If the pump fails and the unit must be used before it can be replaced, the condensate can be drained by gravity (see Sec. 4.9).

2.5 Ducting

A detachable 8" round exhaust collar is supplied that will allow round flexible duct to be attached to the Phoenix 200 outlet. The duct may be permanently attached to the collar. The duct and collar may then be quickly attached to the Phoenix 200 by sliding the 4 collar tabs into the slots around the blower outlet and rotating the collar clockwise. It may be quickly removed to transport the unit more easily.

Duct Sizing: For total duct lengths up to 25', use a minimum 8" diameter round flexible duct. For longer lengths, use a minimum 10" diameter.

2.6 Power Switch

The power switch (on left side of hour meter) lights up when the unit is turned on. The unit will continue to run in all conditions until the switch is turned off; there is no dehumidistat. If the unit is going to run for more than 2 hours in an area below 50°F, the defrost timer should be adjusted to improve performance (see Sec. 2.9).

2.7 Pump Purge Switch

This switch (on right side of hour meter) minimizes the water left in the condensate pump reservoir for moving or storage. Pressing and holding the pump purge switch will cause the condensate pump to run. Hold the switch in until the flow from the condensate hose stops.

2.8 Hour Meter

The digital hour meter measures the cumulative time that the unit is turned on to tenths of an hour. It stores its total when the unit is unplugged; the previous total will be displayed when the unit is next turned on. It resets to zero after 99,999.9 hours of operation.

2.9 Defrost Control Adjustment

When the Phoenix 200 is used in a cool area, frost will form on the cooling coil as it dehumidifies. When enough frost forms, the defrost thermostat will initiate the timed defrost cycle. The cycle periodically turns off the compressor while allowing the blower to run. The frost is melted by the air that the blower draws through the cooling coil.

DRYING TIP: Air's ability to absorb moisture from wet surroundings and the Phoenix 200's ability to remove moisture from that air is greatly improved at higher temperatures. We recommend that the area to be dried be heated to over 70°F if possible. Less drying time will be required and efficiency will improve.

The defrost cycle is automatic and designed for optimum performance above 50°F. If the unit is used in an area that is below 50°F for more than 2 hours, adjustment of the defrost timer is recommended. To adjust the defrost timer:

1. Unplug the unit.
2. Remove the front cover (6 screws).
3. The timer is fastened to the left inside panel. Every fourth peg around the dial is pushed out from the dial center except one section with 5 pegs out in a row. See figure 1. Each fourth "out" peg represents 15 minutes of compressor "off" time during every hour that the unit is in the defrost cycle.
4. To improve performance below 50°F, the compressor "off" time must be increased to 30 minutes per hour to allow the frost to completely melt. To do this, push the pegs out from the dial center so that the pegs alternate with 2 toward the center, then 2 out from the center, all the way around the dial except for the section now with 6 pegs out in a row (see Fig. 1).
5. Replace the cover.

Change the timer pegs back to the original pattern for use above 50°F.

3 Maintenance

3.1 Air Filter

The Phoenix 200 is equipped with a pleated fabric air filter that must be checked regularly. Operating the unit with a dirty filter will reduce the dehumidifier's capacity and efficiency and may cause the compressor to cycle off and on unnecessarily on the defrost control.

The filter can generally be vacuumed clean several times before needing replacement. Replacement filters can be ordered from the factory or purchased locally if available. **DO NOT** operate the unit without the filter or with a less effective filter as the heat exchange coils inside the unit could become clogged and require disassembly to clean.

3.2 Blower Oiling

The blower motor is factory lubricated for many years of normal operation; however, periodic oiling will extend motor bearing life. To oil, remove the plastic cap from the two oiling tubes extending from the unit above and to the right of the blower outlet (see Figure 4). Add 3 to 5 drops of SAE 20 non-detergent oil to each tube every 1000 hours of operation. **DO NOT** use thinner oil or penetrating oil; blower life can actually be decreased by such oil.


3.3 Storage

There are two issues to consider when the Phoenix 200 is stored between uses and both pertain to the water trapped in the unit: damage caused by freezing or biological growth. The effect of the trapped water can be greatly reduced if precautions are taken to remove as much as possible before storage.


1. Use the pump purge switch (see Sec. 2.7 & Fig. 4) to reduce the water level in the reservoir.
2. Stretch the hose flat to drain it completely.

If the unit will not be exposed to freezing temperatures, an alternative to reduce biological growth is to flush the unit with a bio-fungicide that is approved for use with copper, aluminum and polyethylene. To flush:

1. Run the hose to a drain.
2. Plug in the unit but do not turn it on.
3. Remove the air filter. Slowly pour a quart of the chemical through the top grille so that it drains into the white plastic slots.
4. Hold in the pump purge switch to reduce the water level in the reservoir.



Above 50°



Below 50°

Figure 1: Defrost Timer Adjustment

2.10 Low Pressure Control

If the low side refrigerant pressure drops to 15 PSIG, the low pressure control opens and shuts off the compressor and blower. It is an automatically reset control. Its primary function is to prevent damage to the compressor if a leak develops in the refrigeration system. It may also open if the unit is A) used in a cool area (below 50°F) and the defrost timer is not adjusted (see Sec. 2.9) or B) stored where it is below 40°F and then started. Under these conditions, the unit will restart within several minutes; it may cycle several times until the unit warms up.

4 Service

CAUTION: Servicing the Phoenix 200 with its **high pressure** refrigerant system and **high voltage** circuitry presents a health hazard which could result in **death**, serious bodily **injury**, and/or **property damage**. Only qualified service people should service this unit.

4.1 Warranty

A warranty certificate has been enclosed with this unit; read it before any repair is initiated. If a warranty repair is required, call the factory first at 1-800-533-7533 for warranty claim authorization and technical assistance.

4.2 Technical Description

The PHOENIX 200 uses a refrigeration system similar to an air conditioner's to remove heat and moisture from incoming air, and to add heat to the air that is discharged (see Fig. 2).

Hot, high pressure refrigerant gas is routed from the compressor to the condenser coil; see Figure 2. The refrigerant is cooled and condensed by giving up its heat to the air that is about to be discharged from the unit. The refrigerant liquid then passes through a filter/drier and capillary tubing which cause the refrigerant pressure and temperature to drop. It next enters the evaporator coil where it absorbs heat from the incoming air and evaporates.




Figure 2: Refrigeration system of Phoenix

The evaporator operates in a flooded condition, which means that all the evaporator tubes contain liquid refrigerant during normal operation. A flooded evaporator should maintain constant pressure and temperature across the entire coil, from inlet to outlet.

The mixture of gas and liquid refrigerant enter the accumulator after leaving the evaporator coil. The accumulator prevents any liquid refrigerant from reaching the compressor. The compressor evacuates the cool refrigerant gas from the accumulator and compresses it to a high pressure and temperature to repeat the process.

4.3 Troubleshooting

No dehumidification, neither blower nor compressor run and power switch does not light when ON.

1. Unit unplugged or no power to outlet.
2. Power switch defective (Sec. 2.6).
3. Loose connection in internal wiring (Fig. 3).

No dehumidification, neither blower nor compressor run with power switch ON & lit.

1. Low pressure control open (Sec. 2.10).
2. Power switch defective (Sec. 2.6).
3. Loose connection in internal wiring (Fig. 3).

Some dehumidification, blower runs continuously but compressor only runs sporadically.

1. Unit is in defrost cycle (Sec. 2.9 & 4.7).
2. Defrost thermostat defective or loose (Sec. 2.9 & 4.7).
3. Loose connection in compressor circuit (see Fig. 3).
4. Defective compressor overload (Sec. 4.6A).
5. Defective compressor (Sec. 4.6).
6. Defective relay (Sec. 4.10).

No dehumidification, blower runs but compressor does not.

1. Bad connection in compressor circuit (Fig. 3).
2. Defective compressor capacitor (Sec. 4.6A).
3. Defective compressor overload (Sec. 4.6A).
4. Defective compressor (Sec. 4.6).
5. Defective relay (Sec. 4.10).

Blower does not run. Compressor runs briefly but cycles on & off.

1. Loose connection in blower circuit (see Fig. 3).
2. Obstruction prevents impeller rotation.
3. Defective blower (Sec. 4.5).

Unit removes some water but not as much as expected.

1. Air temperature and/or humidity have dropped.
2. Humidity meter and/or thermometer used are out of calibration.

3. Unit has entered defrost cycle (Sec. 2.9 & 4.7).
4. Air filter dirty (Sec. 3.1).
5. Defrost timer incorrectly set for conditions (Sec. 2.9 & 4.7).
6. Defective defrost thermostat (Sec. 4.7)
7. Low refrigerant charge (Sec. 4.4).
8. Air leak such as loose cover.
9. Defective compressor (Sec. 4.6).
10. Restrictive exhaust ducting (Sec. 2.5)

Unit runs but does not pump water.

1. Hose kinked or plugged.
2. Pump motor or float switch defective (Sec. 4.8).
3. Pump check valve plugged (Sec. 4.8).
4. Bad connection in pump circuit (Fig. 3).
5. Hose disconnected internally.

Unit pumps water automatically but not when purge switch is pushed.

1. Bad connection in purge switch circuit (Fig. 3).
2. Defective purge switch (Sec. 2.7).

Evaporator coil frosted continuously, low dehumidifying capacity.

1. Defrost thermostat loose or defective (Sec. 2.9 & 4.7).
2. Defrost timer incorrectly set or defective (Sec. 2.9 & 4.7).
2. Low refrigerant charge (Sec. 4.4).
3. Dirty air filter or air flow restricted. (Sec. 3.1).

Compressor runs with power switch OFF.

1. Defective relay (Sec. 4.10).
2. Defective power switch (Sec. 2.6)

4.4 Refrigerant Charging

If the refrigerant charge is lost due to service or a leak, a new charge must be accurately weighed in. If any of the old charge is left in the system, it must be removed before weighing in the new charge. Refer to the unit nameplate for the correct charge weight and refrigerant type.

4.5 Blower Replacement

The centrifugal blower has a PSC motor and internal thermal overload protection. If defective, the complete assembly must be replaced.

1. Unplug the power cord.
2. Remove the cabinet front (6 screws).
3. Disconnect the blower leads.
4. Pull the oil tubes out of the motor.
5. Remove the four screws holding the blower outlet flange to the cabinet end.
6. Rotate the blower outlet toward you as you remove it. Use care to avoid hooking wiring, tubing or electrical components.

7. Reassembling with the new blower is the above procedure reversed.

4.6 Compressor/Capacitor Replacement

This compressor is equipped with a two terminal external overload, run capacitor, but no start capacitor or relay (see Fig. 3).

CAUTION-ELECTRICAL SHOCK HAZARD: Electrical power must be present to perform some tests; these tests should be performed by a qualified service person.

4.6A Checking Compressor Motor Circuits

Perform the following tests if the blower runs but the compressor does not with the power switch ON.

1. Turn the power switch OFF and unplug the unit, remove the cabinet front (6 screws).
2. Plug in the unit and turn the power switch ON. Use a voltmeter to check for 110 to 120 volts between (a) the relay terminal that the black wire from the compressor connects to and (b) the capacitor terminal with the 2 white wires & blue wire connected. If voltage is present, go to step 3. If no voltage, the low pressure control or relay are open or there is a loose connection in the compressor circuit. Test each component for continuity; see the appropriate section if a defect is suspected.
3. Turn the power switch OFF and unplug the unit, then disconnect the red and yellow wires from compressor terminals R & S. Using an ohmmeter, check continuity between the points listed below.
4. Compressor terminals C and S: No continuity indicates an open start winding; the compressor must be replaced. Normal start winding resistance 3 to 7 ohms.
5. Compressor terminals C and R: No continuity indicates an open run winding; the compressor must be replaced. Normal run winding resistance is .5 to 2 ohms.
6. Compressor terminal C and overload terminal 1: No continuity indicates a defective overload lead.
7. Overload terminals 1 and 3: If there is no continuity, the overload may be tripped; wait 10 minutes and try again. If there is still no continuity, it is defective and must be replaced.

8. Compressor terminal C and compressor case: Continuity indicates a grounded motor; the compressor must be replaced.
9. Disconnect the wires from the capacitor. Set the ohmmeter to the Rx1 scale; the capacitor is shorted and must be replaced if continuity exists across its terminals. If there is no needle movement with the meter set on the Rx100000 scale, the capacitor is open and must be replaced.
10. Reconnect the wires to the compressor and capacitor; plug in and turn on the unit. If the compressor fails to start, replace the run capacitor.
11. If the unit still does not start, adding a hard-start kit will provide greater starting torque. If this does not work, the compressor has an internal mechanical defect and must be replaced.

4.6B Replacing a Burned Out Compressor

The refrigerant and oil mixture in a compressor is chemically very stable under normal operating conditions. However, when an electrical short occurs in the compressor motor, the resulting high temperature arc causes a portion of the refrigerant oil mixture to break down into carbonaceous sludge, a very corrosive acid, and water. These contaminants must be carefully removed otherwise even small residues will attack replacement compressor motors and cause failures.

The following procedure is effective only if the system is monitored after replacing the compressor to insure that the clean up was complete.

1. This procedure assumes that the previously listed compressor motor circuit tests revealed a shorted or open winding. If so, cautiously smell the refrigerant from the compressor service port for the acid odor of a burn out. **WARNING:** The gas could be toxic and highly acidic. If no acid odor is present, skip down to the section on changing a non-burn out compressor.
2. Remove and properly dispose of the system charge. **DO NOT** vent the refrigerant or allow it to contact your eyes or skin.
3. Remove the burned out compressor. Use rubber gloves if there is any possibility of coming in contact with the oil or sludge.
4. To facilitate subsequent steps, determine the type of burn out that occurred. If the discharge line shows no evidence of sludge and the suction line is also clean or perhaps has some light carbon deposits, the burn out occurred while the compressor was not rotating. Contaminants are

therefore largely confined to the compressor housing. A single installation of liquid and suction line filter/driers will probably clean up the system.

If sludge is evident in the discharge line, it will likely be found in the suction line; this indicates the compressor burned out while running. Sludge and acid have been pumped throughout the system. Several changes of the liquid and suction filter/driers will probably be necessary to cleanse the system.

- 5) Correct the system fault that caused the burn out. Consult the factory for advice.
- 6) Install the replacement compressor with a new capacitor and an oversized liquid line filter.

In a running burn out, install an oversized suction line filter/drier between the accumulator and compressor. Thoroughly flush the accumulator with refrigerant to remove all trapped sludge and to prevent the oil hole from becoming plugged. A standing burn out does not require a suction line filter/drier.

- 7) Evacuate the system with a good vacuum pump and accurate vacuum gauge. Leave the pump on the system for at least an hour.
- 8) Operate the system for a short period of time, monitoring the suction pressure to determine that the suction filter is not becoming plugged. Replace the suction filter/drier if pressure drop occurs. If a severe running burn out has occurred, several filter/driers may have to be replaced to remove all of the acid and moisture.

NOTE: NEVER use the compressor to evacuate the system or any part of it.

4.6C Replacing a Compressor- Non-Burn Out

Remove the refrigerant from the system. Replace the compressor and liquid line filter/drier. Charge the system to 50 PSIG and check for leaks. Remove the charge and weigh in the refrigerant quantity listed on the nameplate. Operate the system to verify performance.

4.7 Defrost Thermostat & Timer

The defrost thermostat is attached to the refrigerant suction tube between the accumulator and compressor. If the low side refrigerant temperature drops due to excessive frost formation on the evaporator coil, the thermostat opens. The compressor is then cycled off and on by the defrost timer. The blower will continue to run, causing air to flow through the evaporator coil and melt the ice when the compressor is off. When the air temperature and/or humidity increase, the evaporator temperature will rise and the thermostat will close to end the defrost cycle.

To improve performance in low temperatures, see Sec. 2.9 for defrost timer adjustment.

4.8 Condensate Pump

Condensate is automatically pumped when the water level in the pump's reservoir rises to close the float switch or if the pump purge switch is held in.

To replace the condensate pump:

1. Remove the blower (see Sec. 4.5).

2. Remove the plastic strap holding the pump. It may be reused by using a small screw driver to disengage the tightening pawl on the strap end.
3. Disconnect the leads. The lead that connects to the pump purge switch may be easier to cut and wire nut to the new pump than to disconnect.
4. Installation is the reverse of above, but check that the plastic inlet & outlet hoses do not rub against copper refrigerant tubes.


4.9 Gravity Drain Option

If the condensate pump fails and cannot be replaced immediately, the Phoenix 200 can be used by draining by gravity.

1. Unplug the unit & remove the front cover.
2. Push the plastic plug on the right side (see Fig. 4) out from inside the unit.
3. Locate the heavy vinyl hose that connects the drain pan to the condensate pump; pull the end out of the pump & remove the garden hose connection from it.
4. Push that end of the vinyl hose through the hole in the right side. Re-insert the garden hose connection in the hose end.
5. Connect a garden hose & run it to a drain. Keep the hose as flat to the floor as possible to avoid air pockets that would hinder draining. Placing the unit on something above the floor will also improve draining.

4.10 Relay

The contacts of the single pole, single throw relay complete the power circuit to the compressor. The contacts are closed when power is provided to the relay coil via the control circuit; the control circuit includes the power switch, low pressure control, defrost thermostat and timer.



Therma-Stor Products
P.O. Box 8050, Madison, WI 53708
Phone Toll Free 1-800-533-7533

PART NO.	REV.
4021790	A

Figure 3: Electrical Schematic of Phoenix 200

SERVICE PARTS LIST: Phoenix 200 Dehumidifier

ITEM	PART NO.	QTY.	DESCRIPTION
1	4022254	1	Accumulator
2	4021799	1	Air Filter, Pleated, 2" x 16" x 16" (Grainger P/N 5W978)
3	4022037	1	Blower w/ Capacitor (Fasco 7090-1874)
4	4021589	2	Capillary Tubes, .050" ID x .114" OD x 28" long
5	4023390	1	Compressor, Carlyle (P/N EAA090111A)
	4021811	1	Compressor, Tecumseh (P/N RKA5490EXA) (not shown)
6	4022476	1	Overload, Carlyle Cprsr (included with compressor)
	4020733	1	Overload, Tecumseh Cprsr (TI P/N MRA4761-114) (not shown)
7	4021821	1	Condensate Pump
8	4021396	1	Condenser Coil
9	4021787	1	Cord & Wire Harness
10	4021908	1	Drain Hose (.38 ID x .56 OD x 33' long)
11	4021913	1	Outlet Collar (for Ducting Outlet)
12	4021395	1	Evaporator Coil
13	4020955	1	Filter/Drier
14	4021597	1	Hour Meter
15	4021910	1	Instruction Label
16	4022219	1	Low Pressure Control (Ranco P/N 070-127000-D01)
	4021813	1	Low Pressure Control (Robertshaw P/N AP20-2055) (not shown)
17	1970010	1	Relay (Grainger P/N 4A711)
18	4017799	1	Run Capacitor, Tecumseh & Carlyle Cprsr, 25 MFD, 370v
19	4021997	4	Spring
20	4021796	1	Pump Purge Switch
21	4021822	1	Power Switch
22	4021470	1	Thermostat, Defrost
	4021648	1	Mounting Clip, Defrost Thermostat
23	4021823	1	Timer, Defrost
24	4021591	2	Wheel, 10", plastic
	4021609	2	Pin,Hair,Cotter,Zp,.125 X .75
25	4021790	1	Wiring Diagram (on Cover) (not shown)
26	4021950	1	Ground Fault Interrupter (optional)
27	4023079	1	Coupling, Body, Quick Connect, .38 Tube (not shown)
28	4023080	1	Coupling, Insert, Quick Connect, .38 Tube (not shown)




Figure 4