



- 1499-31 Pin Plate Fasteners Only (7)
- 1500-1 Handle
- 1500-2 Head, Tube & Adjusting Knob Assy.
- 1500-3 Thruster Tube w/Studs
- 1500-4 Ratchet and Thruster Assembly
- 1500-5 Nylon Bearing Set
- 1500-6 Dog
- 1500-7 Lock Spring
- 1500-8 Lock Button w/Fasteners (3)
- 1500-9 Dog Pin w/Fasteners (4)
- 1500-10 Ratchet Pin w/Fasteners (4)
- 1500-11 Handle Pin w/Fasteners (4)
- 1500-12 Saddle Pin w/Fasteners (4)
- 1500-13\*\* Saddle Fasteners Only (4)
- 1500-14 Lifting Handle w/Fasteners (2)
- 1500-15 Tail Block Right Half
- 1500-16 Tail Block Left Half
- 1500-17 Tail Block Pivot Tube
- 1500-18 Tail Block Lock Pin
- 1500-19 Tail Block Bushing
- 1500-20 Tail Block Cap Screw
- 1500-21\* Tail Block Wheel Fasteners (2)
- 1500-22 Brass Washer
- 1500-23 Folding Tail Block Complete
- 1500-24 Folding Tail Block Repl. Pads
- 1500-33 1/4-20 x 1/2" Truss Head Screws (2)
- 1500-34 Lock Button Fasteners Only (2)
- 1500-35 Handle Bushing Set (4)
- 1500-36 Head Bushing Only
- 1500-37 Pin Clip & Cap Set (4)
- 1375-G Handle Grip Only
- 1499-M2 NEW Wide Metal Latch Set (2)
- 1500-A Pin Plate w/Screws (7)
- 1500-E\*\* Saddle Casting & Fasteners (4)
- 1500-F Depth Bar w/Screws (2)
- 1500-P Spring Clip
- 1500-Q 2 Piece Transfer Tube
- 1500-S Pin Plate Pins (10)
- 1500-U DRIVING HEAD COMPLETE
- 1500-V\* Wheels Set (2) & Screws (4)
- 1516-A Aluminum Tube Spring Clip

\*To completely replace wheels (2), both 1500-21 and 1500-V are needed

\*\*1500-13 & 1500-E do not come with studs.

Must be factory assembled on 1500-3. 1500-E comes w/fasteners for both new & old style stretchers.