



PLEASE RINSE EACH NIGHT WITH H2O

- Adjustable cone tips are available
- Extra jugs available for different solutions
- Never wash out a tank again

Please Scroll Down to view Part Numbers, Descriptions, & List Prices.

To service the SPRAY1: Unplug from electrical outlet. Remove the 3 black nylon buttons from the bottom of the housing (they are reusable) with a straight blade screw driver. Carefully remove the bottom of the housing with screwdriver.

Part Number Description

* SPRAY1WAND	Complete Wand(1-4)	8004 Stainless Steel Vjet Tip
1 H1/8VV-SS8004	8004 Stainless Steel V-Jet (8004 or 5001 Brass \$5.42)	
2 66CA-4-2	Brass Comp. 1/8"female	
3 SS18	Stainless tube(15")	
4 68CA-4-4	Brass Comp. 1/4"male	
5 6590	Brass/SS, Trig/valve(kit bel.)	
6 H14-2MUSBR	Brass Compression and Strain Relief	
7 FW-6	6 Ft. Coil Hose, 1/4" I.D., includes #H14-2MUSBR	
8 SNP-2	Snap Clamp	
9 TE-2024	Nylon Barb(st) inc. w/pump	
10 508-224	50 psi pump, 115V, viton seals, includes barbs	
11 TA-1024	Nylon Barb(90)inc. w/pump	
12 NA-22	Polyurethane Hose 1/4" I.D., includes strainer and cap/grommet	
13 13862-50	Brass/SS Strainer	
14 1G	1 Gallon Container	
15 SR7W-2	Power Cord Relief Grom.	
16 CORD30	30 Ft. Power Cord	
17 1600ORANGE	Lighted Switch	
18 VEL	2 Inch Velcro Ret. Band	
19 11375K35	Cap with grommet	
* ARD	Black nylon buttons	
* 6590-ORING	Valve Repair O RING only	