



## OWNER'S MANUAL

# Interceptor HEPA Filter



### TABLE OF CONTENTS

ABOUT THE INTERCEPTOR HEPA FILTER

GETTING TO KNOW THE INTERCEPTOR HEPA FILTER

HOW TO SETUP THE INTERCEPTOR WITH THE NEW NON-OPENING STYLE HP60

WARRANTY

CUSTOMER SERVICE

CONTACT US


## ABOUT THE INTERCEPTOR HEPA FILTER

Your Interceptor HEPA filter has three basic parts: rotomold enclosure, the HEPA filter (rated by UL to be 99.97% efficient) and the pre-filter. If used correctly, it will help protect your customer and equipment from exposure to particulates. Your HEPA filter's life will depend on the amount of jobs it is used on and the amount of debris collected. Use your best judgment. TIP: It is best to be prepared and have a replacement filter in your inventory.

## GETTING TO KNOW THE INTERCEPTOR HEPA FILTER


The INTERCEPTOR HEPA FILTER's rotomolded housing is made from medium density polyethylene and is very easy to clean with warm soapy water. The granite color will help hide normal scratches and dings that happens to all active drying equipment.

The INTERCEPTOR HEPA breaks down into 4 pieces: (1 & 2) AIR IN and AIR OUT sides of the rotomold, (3) HEPA filter, and (4) the pre-filter (pictured below right).





Each INTERCEPTOR HEPA ships with the following parts:


(6) AIR IN hose with QC Main T, quantity 1. (5) AIR OUT hose (feeds from the HEPA to the HP System), quantity 1, (pictured right).



## HOW TO SET UP THE INTERCEPTOR WITH THE NEW NON-OPENING STYLE HP60



You will remove either the Main AIR IN Hose's Main T (EX 1 above) or disconnect the entire Main AIR IN Hose just behind the Pressure Relief Valve (EX 2 above). Picture 1 shows the current AIR IN Main Hose before you make modifications. Picture 2 above shows the example 1 being used. The INTERCEPTOR AIR OUT hose is fitted with a male pipe thread in 2 inch.



After you have completed the steps above, now attach the Hose Cuff side of the INTERCEPTOR AIR OUT Hose to the AIR OUT port of the INTERCEPTOR HEPA filter (Pic 3 above). Finally, attach the INTERCEPTOR AIR IN Hose. Your INTERCEPTOR is now ready to protect your equipment and the occupants! (Pic 4 above).

## WARRANTY

### Interceptor Roto-Molded Housing Warranty - 7 Years

Injectidry Systems guarantees the roto-molded housing to be free from defects in materials and workmanship for a period of seven (7) years from the original purchase date. This warranty is subject to the conditions listed below.

#### CONDITIONS OF WARRANTY

**Roto-Molded Housing Warranty:** Injectidry Systems will repair or replace for the original purchaser (at Injectidry's option), the parts necessary to correct any defects in materials and workmanship for a period of seven (7) years. During the first year, Injectidry Systems will cover all material, labor, and shipping costs to and from the service center. The customer is responsible for all labor and shipping costs after one (1) year from the original date of purchase.

**Limitations:** This warranty will not extend to Injectidry products showing any accidental damage, alteration, normal wear, disassembly, lack of proper maintenance, damage from fire or flood, damage from corrosive or other chemicals, unauthorized repairs, use of non-genuine parts and materials, misuse, or any other causes beyond the control of Injectidry. The warranty obligation extends only to the repairs or replacement of parts found to be defective upon the examination and the decision of Injectidry Systems.

The preceding limitations constitute the entire warranty. No other warranty or responsibility is expressed or implied. The warranty includes legal rights to the original purchaser, and additional rights may be available, varying state to state. In addition, Injectidry Systems Repair Department must authorize all incoming products and/or repair work to be completed by an authorized repair center. Injectidry Systems is not responsible for any repairs or modifications to any of its products, unless completed by Injectidry Systems or an authorized service center. We are not responsible for subsequent damaged caused by the user and or its agents.

## CUSTOMER SERVICE

If you need technical support or to order parts, please call customer service. Our commitment is to take care of your needs in a fast and courteous fashion.

### Incomplete Shipments

All shortages must be reported within five business days of receipt of goods.

Be sure to check the number of cartons or packages. You can compare this count with the total listed on Bill of Lading. Confirm that you have received all cartons or packages pertaining to this shipment.

If quantities do not match, have the delivery person note shortage. If the missing cartons or packages do not show up in the next few days, contact the Shipping Department and we will reship on a new order.

You must file a Freight Claim for shorted packages if the count differs from the Bill of Lading. For your protection, the carrier who delivers merchandise to your door is responsible for any loss or damages. Acceptance of the shipment by the carrier company is acknowledgement that the articles were delivered to them were in good condition and properly packaged.

### Freight Damage

Orders are shipped Freight on Board (F.O.B.) from our warehouse in Lynnwood, WA. Once the product has shipped to the customer, it is the customer's responsibility. We will assist the customer in filing for any freight damage claims but these claims must be filed with us within two working days of receipt of the items.

We suggest that you carefully inspect your shipment upon receipt. If there is visible damage, note this on the waybill before you sign and notify the carrier immediately.

Please contact our shipping department or customer service right away.